





Double brake system

G= 0

Fold in 3 seconds



Lithium-electronic batteries



Anti-theft system

Lighting the lights



Shock-absorbing system



LOAD 200KG

▶ PRODUCT INTRODUCTION





30-35/60-80

36V10AH/48V15AH LONG-TERM BATTERY LIFE

SAFETY-POWERED LITHIUM BATTERY

Lithium battery









Dashboard 1

Gear switch (2)

Power switch 3

Accelerator handle



REMOTE ANTI-THEFT ALARM








brake system



DISC BRAKE













SHOCK ABSORBER THE FRONT WHEEL SUSPENSION +THE REAR SUSPENSION



Masonry

Cement

Grass







Electric Scooter Specifications

Motor power	36v 350w rear drive / 46v 500w rear drive	Battery Capacity	36v 6ah/7.8ah/8ah/10ah/12ah/13ah/15ah/18ah/20ah and 48v 4ah/5ah/6ah/7.5ah/8ah/10ah/12ah/13ah/ 15ah/16ah/17.5ah/20ah/22.5ah
Rated voltage	36V/48v	Certification	CE, ROSH, MSDS, etc
Charging time	4-6h	Max Load capacity	150kg
Brake system	F/R disc brake	Lighting system	Front LED light, Rear brake light, Flashing light, Turn light
Max battery life	20-100km	Max Speed	25-45km/h; 1-3 speed levels
Tire	10" air tire	Tire upgrades optional	10" vacuum tire
Rated current	2A	Charging Input Voltage	42V
Rated I/O voltage	110-220V	Waterproof level	IPSS
Climbing ability	25 degree	N.W/G.W	17kg/18kg
Expand size	110*24*(80- 120)cm	Foldable size	120*26*37cm
Operating temperature	-5°C ~ 40°C	Storage Temperature	-23°C ~ 40°C
Fuctions	Bluetooth for music; Anti-theft alert;		
Spare parts optional	Seat with suspension; Front basket; Pedal pad; Customized requirements		



Aftersales Policy

Receive package during shipping:

1. Please must check and confirm the package condition. If the package is damaged or wet, take photos or videos first, open the box at once to check scooter condition. If there is broken part or customer can not turn on the scooter, please reject the package immediately and ask courier for claim or customers can send us photos or videos, we will contact shipping company for claims.

2. If the package is in good condition and customer signs, this shipment is acceptable. Any broken conditions caused by shipping will be not our responsibility.

Check hardware:

Turn on the scooter and fully check step by step as below for reference:

1. Charge the scooter for 6-8 hours to make sure the battery has full electricity, normally when charger's light turns green, the charging is finished.

2. Fully check the scooter performance including: fold and unfold the scooter, braking condition, lighting condition(front light, brake light, turn signal light, etc), speaker sound condition, alarm performance, wheel condition, etc.

If there is technical problems after you do checking as above:

1. Take photos or videos to describe the problems, we will help you with maintenance instructions.

2. Keep the whole package including box, fixed fillings, user manual, tools, spare parts, etc as original packing in 15 days if you need to return. The impact of the second product is not a return policy areas.

For non-human damage and failure, provide After-sales service in accordance with the following terms:

1. Main parts

The warranty period of battery, controller, motor is 12 months. Free accessories are available. *Note:*

Be sure that motor has no crush, human damage, water intake, repair on your own.

Be sure that the controller is without water intake, crush, improper operation to cause current overload.

Be sure that the battery house is without water intake, pedal or bottom pad is not broken, battery is charged with compatible charger.



2. Minor parts

Warranty period is 6 months.

Free accessories are available. Meanwhile, we will assist with videos, pictures to show how to maintain by themselves in advance like Folder, Brake, Suspension Shock absorber, Charger, Lights, Display, etc.

3. Wear parts

Hook, tire, brake pad, Kickstand, screws, nuts, etc, not included in after sales service. Accessories will be provided and charged accordingly.

4. Other condition:

Stem and frame is broken apart because of quality issue, we supply full refund or exchange service. Not including crush or wrong operation like crushing into hard objects, etc.

Warranty is not apply to following conditions:

1. The user is not in accordance with the provisions of User Manual to use, maintain and adjust which cause the failure.

2. The users modify, repair the product by themselves to cause the damage, don't comply with the provisions to lead to the failure.

- 3. The users storage it improperly or accident occurs to cause the failure.
- 4. The users do not have the warranty card.
- 5. Appearance damage after using.
- 6. The damage caused by riding in the rain or in the water and soaked in the water.